




TOP AND CONSOLE PARTS

For Model: NED7200TW10

(White)

29"ELECTRIC DRYER

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: NED7200TW10

(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.

Illus.	Part	
No.	No.	DESCRIPTION
1		Literature Parts
	W10161016	Use & Care Guide
	16026881	Tech Sheet
	W10161760	Installation, Instruction
2	6006-00174	Screw-Tapping (2)
3	W10175952	Button, Power
4	W10177362	Panel-Console Assembly
5	35001231	Bracket, Panel (2)
6	35001229	Panel, Control
7	34001419	Lever-Power
8	6002-000470	Screw-Tapping (4)
9	35001269	User-Interface
10	6002-000213	Screw-Tapping
11	35001232	Support-Panel
12	35001162	Frame-Plate
13	6006-001170	Screw-Tapping
14	W10177364	Top
15	6009-001476	Screw-Hex (2)
16	W10175949	Knob, Control
17	35001262	Harness, Main
18	6002-000231	Screw-Tapping (5)


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: NED7200TW10

(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: NED7200TW10

(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	35001157	Cover, Terminal Block	17	W10177398	Seal-Front Panel	30	35001107	Screw-Tapping
2	6006-00174	Screw-Tapping	18	35001168	Bracket, Control Board	31	213121	Screw-Tapping
3	6006-00106	Screw-Tapping	19	35001125	Door-Switch	32	Y059131	4" - 90° Elbow
4	34001481	Block, Terminal	20	35001084	Tri-Ring	33	35001216	Plug-Multivent
5	35001082	Switch, Broken Belt	21	35001112	Catch, Door Assembly	34	35001205	Duct, Exhaust (A)
6	35001156	Bracket, Dryer Foot	22	W10177396	Panel, Front	35	35001204	Duct, Exhaust (B)
7	35001169	Cabinet	23	6002-00213	Screw-Tapping	36	6002-000231	Screw-Tapping
8	35001158	Foot, Dryer	24	35001167	Strain-Relief Power Cord			
9	6002-000239	Screw-Tapping (10)	25	35001254	Kit			
10	35001081	Clamp, Motor (2)	26	35001200	Stack Assembly			
11	35001278	Spring, Idler	27	35001080	Cord, Power			
12	6009-001342	Retainer, Idler	28	35001106	Assembly, Motor			
13	35001086	Pulley Assembly	29	35001171	60 HZ.			
14	35001276	Bracket, Idler			Bracket, Motor			
15	35001137	Belt-Drive			Clip, Harness			
16	35001153	Board, Control						

Optional Parts Not Included

Dryer Exhaust Kit
(For Side & Bottom Venting)

37 12002641 White


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: NED7200TW10

(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: NED7200TW10

(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10177426	Screen, Lint	16	35001109	Box, Heater	28	6002-001320	Screw-Tapping
2	6002-000239	Screw-Tapping	17	W10177410	Bulkhead, Rear	29	35001242	Guide-Sensor
3	35001246	Cover-Plate Assembly	18	35001133	Washer, Support	30	35001146	Channel Bracket, Rear Bulkhead (2)
4	35001243	Grille, Outlet	19	35001140	Assembly, Lint Duct	31	35001145	Bracket, Upper Rear Bulkhead
5	35001135	Air Duct Assembly	20	35001089	Housing-Blower Front	32	6002-000231	Screw-Tapping
6	35001244	Bulkhead, Front	21	W10177428	Assembly, Roller-Support	33	35001088	Blower-Housing Rear
7	35001241	Plate-Sensor	22	34001159	Exhaust Pipe	34	35001245	Guide-Sensor Assembly
8	35001132	Nut-Hex	23	35001144	Housing, Outlet	35	35001104	Bracket, Heater-Box
9	35001131	Baffle-Drum	24	35001105	Bracket-Thermistor	36	6002-00470	Screw-Tapping
10	34001214	Screw-Tapping	25	W10177409	Assembly, Drum	37	35001220	Wheel- Blower
11	35001087	Thermostat	26	6002-000215	Screw-Tapping	38	35001155	Clip-Exhaust
12	35001119	Assembly, Heater Box	27	35001191	Thermistor	39	35001079	Nut-Inch
13	35001092	Thermostat						
14	35001247	Element, Heater						
15	35001193	Assembly-Bracket Thermostat						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: NED7200TW10
(White)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	35001235	Door-Outer Ring	5	35001250	Seal-Door	10	6001-001773	Screw-Machine
2	35001129	Bracket-Hinge	6	W10177441	Holder-Glass	11	6002-000213	Screw-Tapping
3	35001235	Door-Safety	7	35001120	Support-Hinge	12	35001111	Catch-Door
4	35001182	Window	8	W10177442	Hinge, Door	13	6002-000525	Screw-Tapping
			9	35001127	Bearing-Hinge	14	6002-000475	Screw-Tapping

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

**For Model: NED7200TW10
(White)**

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.

Illus.	Part
No.	No.

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White

350938 Primer, Gray

ACCESSORY PARTS

- 35001151 Assy-Flat Wire Harness
- 35001152 Assy, M-Wire Harness (Heater)
- 35001164 Assy, Wire Harness (Touch Sensor)
- 12002643 Hold Down Kit
- 12002641 Kit, Dryer Repair